

DOSE RATE METER

GRAETZ GammaTwin S

Product features

- ▲▲ Small and handy dose rate meter for the measurement of gamma radiation and $H^*(10)$ and ambient dose equivalent $H^*(10)$ (local dose) ¹⁾
- ▲▲ Built-in detector: energy compensated GM tube
- ▲▲ Large digital indication of measured values on LC display (backlit)
- ▲▲ Selectable simultaneous or separate indication of dose and dose rate, additionally analogue indication of dose rate (logarithmic bargraph)
- ▲▲ Display of the dose rate history graph as a search function for the detection of radioactive sources
- ▲▲ 4 preset dose and dose rate alarm thresholds; upon request GRAETZ changes to customer requirements
- ▲▲ Switchable acoustic single-pulse indication
- ▲▲ Automatic and continuous storage of the dose into a non-volatile memory
- ▲▲ Storage of the dose and of set parameters even during battery change
- ▲▲ Permanent self test
- ▲▲ Designed for rough use, housing made of aluminium, protection class IP54 (splash proof)
- ▲▲ Menu-driven user navigation
- ▲▲ Supplied with robust nylon bag
- ▲▲ **Connection facility for an external probe:**
 - **18526 D** or **ABG170** for contamination measurement (α , β , γ)
 - **immersion counter tube** (β , γ)
 - NaI-scintillation probe **2002** for high-sensitive measurements (β , γ)
- ▲▲ **With connected probe:**
 - Display of measured values in cps
 - Display of the pulse rate history graph as a search function for the detection of radioactive sources or contaminations
 - Pre-selectable alarm thresholds: 2x background or 3x background

¹⁾ Detecting personal dose requires a measuring instrument with the measurand $H_p(10)$.



GammaTwin S with contamination probe ABG170

Technical Data	
Indication ranges:	Dose rate: 0 nSv/h – 50 mSv/h Dose: 0 nSv – 1.0 Sv
Measuring ranges:	Dose rate: 0.5 µSv/h – 50 mSv/h Dose: 0.5 µSv – 1.0 Sv Cps: according to technical data of the connected probe
Energy range:	40 keV – 1.3 MeV
Dose rate alarm thresholds:	7.5 µSv/h, 25 µSv/h, 40 µSv/h, 300 µSv/h
Dose alarm thresholds:	200 µSv, 500 µSv, 1 mSv, 2 mSv
Temperature range:	-20 °C up to +60 °C
Dimensions:	Approx. 28 x 67 x 105 mm
Weight:	Approx. 200 g (with batteries)
Power supply:	2 batteries 1.5 V (type AAA)
Acoustic alarm:	approx. 80 dB(A) measured in 30 cm distance